

## Universal Awning Roof mount

### Assembly instructions

#### Content

1x Roof side with 3 holes ( <b>A</b> )	1x Awning side with 5 holes ( <b>B</b> )	2 x Arms ( <b>C</b> )
6 x small Hex Head Cap Screws ( <b>D</b> )	12 x small flat washers ( <b>E</b> )	6 x small nylon Insert locknut ( <b>F</b> )
2 x big Hex head Cap Screws ( <b>G</b> )	4 x big flat washers ( <b>H</b> )	2 x big nylon insert locknut ( <b>I</b> )

#### Disclaimer

The following instruction describes how to use the hardware to assemble our Awning roof mount.

The installation to the roof or the global process to install the awning is not described in this document. Indeed, you might want to customize the steps below to make the installation easier. It will depends of every roof and every job site.

#### Assembly

1. Mount your awning wall bracket to part **B**. 5 Holes are available in part **B**, use the one that line up with your Awning bracket.  
Harware needed : 2 x **G** + 4 x **H** + 2 x **I**. Pattern: **G + H + bracket + H + I**
2. Connect **C** to the part **B**  
Harware needed : 2 x **D** + 4 x **E** + 2 x **F**. P attern: **D + E +B +C + E + D + F**
3. Connect part **A** part **B** using the round holes located on the sides of each part.  
Harware needed : 2 x **G** + 4 x **H** + 2 x **I**. Pattern: **G + H + bracket + H + I**
4. Connect **C** to part **A**. Many holes are available in part **A**, use the one that will offset your roof pitch to create a 90 degree angle with the roof bracket